

ATTACHMENT OF WINDOW SURROUND TO WOOD

WITH LINTEL & SCREWS & I-WAY STRAP & DOWEL & WIRE