



Technical Information: Cutting Details


For: Balustrade Step Handrail



Easing over Tangent Cut Detail. Cut Ease Over where the Radius is tangent to the Sloped Handrail as shown above. This provides a much cleaner transition and elegant look.




Mitered molding straight parts to be joined at a transition point. Provide the Mitered cut look without the hassle of field cutting. Making your Mason's life easier.



Beveled Handrail Cutting Detail. Field cut as shown. Often the Masons will charge more than what we might charge to make the joints shown in the previous two examples.


Attachments & Interface Balustrade

Drill & Pin Balustrades






Steel pins are the most commonly used method to assemble Balustrade

Drill a $\#1$ " x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.
Use a $\#1/2$ " x 2" long steel pin to secure the stones.




Drill a $\#1$ " x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.
Use a $\#1/2$ " x 2" long steel pin to secure the stones.




Attachments & Interface Balustrade

Drill & Pin Balustrades




Steel pins are the most commonly used method to assemble Balustrade



Drill a $\varnothing 1"$ x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.

Use a $\varnothing \frac{1}{2}"$ x 2" long steel pin to secure the stones.




Drill a $\varnothing 1"$ x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.


Use a $\varnothing \frac{1}{2}"$ x 2" long steel pin to secure the stones.

Attachments & Interface Balustrade

Drill & Pin Balustrades




Steel pins are the most commonly used method to assemble Balustrade



Drill a $\varnothing 1"$ x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.

Use a $\varnothing \frac{1}{2}"$ x 2" long steel pin to secure the stones.




Drill a $\varnothing 1"$ x 1.25 deep hole into both stones. Remember to align the stone and holes properly before drilling the holes.

Use a $\varnothing \frac{1}{2}"$ x 2" long steel pin to secure the stones.


Technical Information: Profile Setting Beds

For: Balustrade system to ensure Rail profile, Baluster and Base profiles match up.




Extrados1 Rail
Otterwood1 Baluster
Chamfer1 Base

Profile Setting Bed 7 inches




Binelli2 Rail
Noble Baluster
Verona2 Base

Profile Setting Bed 5 inches



Connelly1 Rail
Kendal Baluster
Cove1 Base

Profile Setting Bed 6 1/2 inches



Benelli1 Rail
Florentine Baluster
Verona1 Base

Profile Setting Bed 7 inches