


How to Attach a Window Surround



How to Attach a Window Surround




How to Attach a Window Surround



SCALE: 1" = 1'-0"


Cutting & Fitting of a Keystone

Window Surround to Profile Based Sill, CUTTING DETAILS



SCALE: NTS.

Cutting & Fitting of a Keystone



Cutting & Fitting of a Keystone

